

1050 Heinz Avenue, Berkeley, California 94710 • (510) 848-4411 • www.alternativetechs.com

HOW TO: CHANGE THE TIME ON YOUR DISPLAY

(for NEC SV8100 and SV9100 Phone Systems)

- 1. Leave the handset in the cradle
- 2. Press Speaker
- 3. Enter the service code (probably **728**, but may be **828**)
- 4. Enter the accurate time: two digits for the hour and two digits for the minute, using the 24-hour clock ("railroad time"). Note: Although you enter 13:30, it will read 1:30PM on your phone.
- 5. You will hear 3 confirmation beeps. Press **Speaker** to hang up.

it's all connected